

## PACO VLS Cross Section

LABEL	DESCRIPTION
1A	VOLUTE
1C	SET SCREW
2N	SEAL CAP
3A	IMPELLER
4A	CASE WEAR RING
4F	BALANCE RING
6A	PUMP SHAFT
8B	VOLUTE SCREW
8C	PUMP SHAFT SCREW
8E	COUPLING SCREW
8F	COUPLING GUARD SCREW
8G	LOCATING RING SCREW
8N	MOTOR SCREW
11A	VOLUTE GASKET
12B	COUPLING KEY
14A	SEAL ASSEMBLY
15A	LOCATING RING
16A	PIPE PLUG
17E	SEAL CAP O-RING
20J	CAST IRON STAND
21A	MOTOR BRACKET
22A	SEAL CAP STUDS
23D	COUPLING HALVES
24H	BUSHING
34B	IMPELLER WASHER
34C	PUMP SHAFT WASHER
34F	COUPLING GUARD
35F	SEAL CAP NUT
65A	MOTOR

